

Comparison · This Pack vs Cup-Test v4

Pour **BX-01** first — that is the BazzLab card. This page only shows how the older homepage screens and the ChatGPT cup-test differ. Do not blend any of them into one pour.

BX-01 Best

BEST

NEW

The formula others do not publish: TB-307 f = 2.5 instead of Mannich, TEROL 250 aromatic instead of extra TCPP, PO cats instead of K-15 / DMCHA. **HFO-1233zd(E) 10.0 is mandatory**. Faster cream/gel (3–6 s / 8–15 s). Water 1.20. Index 125 → 83 A : 100 B. Run this first.

Cup-test v4 (ChatGPT)

R&D cup plan on CREAPOL 326 / 1500 / PD 230, plus KIMSPRAY 065 LDO / 066 H2C benchmarks. OC is polyether-heavy. CC already includes 10% HFO-1233zd(E) and a K-15 / DMCHA / bismuth set.

What only BX-01 has

POINT	BX-01 BEST	THIS PACK CC-01	CUP-TEST V4 CC
Network	TB-307 / PE 104 41.3 (f = 2.5)	TB-307 / PE 104 35.5	Mannich / sucrose 22.0 + CREAPOL 326 20.0
Flow / fire polyester	TEROL 250 / PE 103 24.8	TEROL 250 / PE 103 24.0	CREAPOL 1500 20.0
Mannich	None	None	Required
HFO in the base	HFO-1233zd(E) 10.0 — mandatory	Must add 10.0 HFO; do not pour water-only	HFO-1233zd(E) 10.0
Water	1.20	2.0	1.1
TCPP	6.0 + TEP 4.0 (aromatic does fire work)	12.0 + TEP 6.5 + rFR 5.0	TCPP 13.0 only
Catalysts	PC-15 1.45, 2040 1.10, CAT-T 0.55, PC-37 0.35 — faster cream/gel	PC-15 1.30, 2040 1.00, CAT-T 0.25, PC-37 0.15	K-15 / DMCHA / XK-614 / MB-20
Mix	83 A : 100 B at index 125	90 A : 100 B at index 120	~100 : 100 after OH check, HFO in

Open cell · OC-01

POINT	THIS PACK	CUP-TEST V4	READ
Main polyols	Sucrose 33.0. No CREAPOL in OC-01.	Polyether 1 24.0 + polyether 2 22.0 + sucrose 15.0 + CREAPOL 1500 5.0	Different backbone
Water	24.0	4.5	v4 is much drier
Flame retardant	TEP 17.0 + reactive FR 8.0	TCPP 23.0	Different FR package
Amine catalysts	10.0 (PC-37 2.4, CAT-T 2.4, PC-15 4.2, BDMAEE 1.0)	3.0 split as blow 1.5 / gel 1.0 / cure 0.5 (same types: BDMAEE, CAT-T, PC-37, PC-15, DABCO 2040)	Same family, much lower dose
Emulsifier / opener	Ecosurf SA-9 6.0	Emulsifier / cell opener 2.0	Lower in v4
Silicone	1.2	1.5	Close
Biocide	0.8	Not listed	Only in this pack
Target density	7–12 kg/m ³	18–24 kg/m ³ (KIMSPRAY 065 LDO ~22)	v4 is denser / more commercial
Cream / gel / rise	2–5 s / — / 8–15 s	4–6 s / 9–12 s / 16–22 s	v4 is slower, spray-like
Open-cell target	< 10 % closed	> 95 %, ideally > 97 %	Both want open cells
Index	Lab 90–105 · spray 35–55	Later series 100 / 105 / 110 after OH check	v4 assumes nearer 1:1

Closed cell · CC-01

POINT	THIS PACK	CUP-TEST V4	READ
High-OH rigid polyester	ISOEXTER TB-307 / KIMpol PE 104 35.5 — replaces CREAPOL 326 GP	CREAPOL 326 GP 20.0	This pack uses more high-OH, lower-cost grade
Flow polyester	TEROL 250 / KIMpol PE 103 24.0 — replaces CREAPOL 1500	CREAPOL 1500 20.0	Same role, close dose
CREAPOL PD 230	7.0	9.2	Same modifier
Mannich / sucrose polyol	Not in CC-01	22.0 — main high-func. rigid polyol	v4 needs an extra polyol

POINT	THIS PACK	CUP-TEST V4	READ
Polyester total	66.5 (TB 307 + Terol 250 + PD 230)	49.2 (CREAPOL 326 / 1500 / PD 230)	This pack is more polyester-heavy
TCP	12.0 + TEP 6.5 + reactive FR 5.0	TCP 13.0 only	This pack has a wider FR split
Physical blowing agent	HFO mandatory. Prefer BX-01. If this screen: +10 HFO, water 1.4	HFO-1233zd(E) 10.0 in the base	v4 starts as HFO hybrid
Water	2.0	1.1	v4 lower CO₂
Silicone	1.4	1.5	Close
Catalysts	PC-15 1.30, DABCO 2040 1.00, CAT-T 0.25, PC-37 0.15	K-15 0.70, DMCHA 1.00, secondary amine 0.70, XK-614 0.50, MB-20 0.30	Different catalyst set
Target density	28–40 kg/m ³	35–40 kg/m ³ (KIMSPRAY 066 H2C ~38)	Overlap at 35–40
Cream / gel / rise	8–15 s / 25–45 s / — · tack-free 40–70 s	4–6 s / 9–12 s / 16–22 s	v4 is faster, closer to 066 H2C
Index / mix	120 calc. → 90.2 g A / 100 g B	Index series 105 / 110 / 115 after OH check. Cup ~100 g A + 100 g B	This pack is 90:100 after the lower-cost grade re-index
Cost note in v4	Not priced on this page	CREAPOL \$2.40/kg; TCP ~\$0.948/kg. Known items ≈ \$130.40 / 100 kg B (HFO and cats not included)	Price only in v4

What to do in the lab

Keep from this pack

Pour **BX-01** first. Use **CC-01** only if BX-01 is too tight or you want the older 90:100 lower-cost swap screen. Use **BX-02** if sucrose is on the floor and you want a commercial open cell. Use **OC-01** only as the high-water memo screen.

Take from cup-test v4

If Mannich/sucrose, polyethers, HFO-1233zd, K-15 / DMCHA and a KIMSPRAY-style target are available, v4 OC (water 4.5, density 18–24) and v4 CC (HFO 10, water 1.1, density 35–40) are closer to commercial spray. Run both bases as 100 g B-side cups and keep one variable at a time.

Closed-cell HFO-1233zd(E) is mandatory. This pack uses ISOEXTER TB-307 / KIMpol PE 104 and TEROL 250 / KIMpol PE 103, which cost less than CREAPOL 326 / 1500. Cup-test v4 still writes the Flokser names and a different catalyst set. Do not blend the two OC-01 formulas into one pour.