

50 g Lab Cup · BX-01

BESTNEW

Closed-cell pour is **50.00 g B (includes 5.00 g HFO-1233zd(E)) + 41.40 g A**. HFO is mandatory. Cream/gel are sped up. Mix 4–5 s. Weigh to 0.01 g.

Cup size	
B-side (HFO in)	50.00 g
of which HFO-1233zd(E)	5.00 g
A-side (PMDI 31 % NCO)	41.40 g
Total	91.40 g
Index	125
Mix	A into B · 4–5 s · 2 500–3 000 rpm
B cup temperature	15–18 °C after HFO

Trial header	
Date	
Operator	
Drum · high-OH	TB-307 / PE 104
Drum · flow	TEROL 250 / PE 103
Cup T	A 21–23 °C · B 15–18 °C
Cup ID	BX-01-50-

BX-01 weigh sheet · 50.00 g B · HFO mandatory

Weigh in this order. Tare a dry, closable B cup. Water before catalysts. **HFO last**, cup at 15–18 °C, cap at once. Write the actual in the last column.

#	INGREDIENT	TARGET G	ACTUAL G
1	ISOEXTER TB-307 / KIMpol PE 104	20.65	
2	TEROL 250 / KIMpol PE 103	12.40	
3	CREAPOL PD 230	2.00	
4	TCPP	3.00	
5	TEP	2.00	
6	Reactive FR	1.00	
7	Emulsifier	0.875	
8	Closed-cell silicone	0.75	
9	Water (deionized / distilled)	0.60	
10	PC-15	0.725	

50 g Lab Cup · BX-02 Open Cell

BESTNEW

Open-cell 50 g cup. **No HFO** on this pour. Only if sucrose is on the floor. Do not blend with BX-01 or OC-01.

Cup size	
B-side	50.00 g
A-side (PMDI 31 % NCO)	65.70 g at index 105
Total	115.70 g
Index	100–110 (calc. 105)
Mix	A into B · 4–5 s · 2 500–3 000 rpm
Cup temperature	A and B 21–23 °C

Trial header	
Date	
Operator	
Sucrose grade / OH#	assumed OH 400 for A-side
Flow polyester	TEROL 250 / PE 103
Cup T (A / B)	21–23 °C
Cup ID	BX-02-50-

BX-02 weigh sheet · 50.00 g B

Weigh in this order. Tare a dry B cup. Water before catalysts. Open-cell silicone only. No HFO. A-side assumes sucrose OH 400 — re-index when the lot OH is known.

#	INGREDIENT	TARGET G	ACTUAL G
1	Sucrose / sucrose polyol	19.00	
2	TEROL 250 / KIMpol PE 103	8.00	
3	TEP	10.45	
4	Reactive FR	3.50	
5	Ecosurf SA-9	2.00	
6	Open-cell silicone	0.75	
7	Water (deionized / distilled)	2.60	
8	PC-37	0.85	
9	CAT-T	0.80	
10	PC-15	1.40	
11	BDMAEE or DEDEE	0.45	